


The IEEE 802.11 family of standards




continued


MIMO




SISO (Single Input Single Output)



MISO (Multiple Input Single Output)



SIMO (Single Input Multiple Output)




MIMO (Multiple Input Multiple Output)


802.11 PHY enhancements

	Wi-Fi 4	Wi-Fi 5	Wi-Fi 6	Wi-Fi 6E	Wi-Fi 7
Launch date	2007	2013	2019	2021	2024 (expected)
IEEE standard	802.11n	802.11ac	802.11ax		802.11be
Max data rate	1.2 Gbps	3.5 Gbps	9.6 Gbps		46 Gbps
Bands	2.4 GHz, 5 GHz	5 GHz	2.4 GHz, 5 GHz	6 GHz	2.4 GHz, 5 GHz, 6 Hz
Channel size	20, 40 MHz	20, 40, 80 80+80, 160 MHz	20, 40, 80 80+80, 160 MHz		Up to 320 MHz
Modulation	64-QAM	256-QAM	1024-QAM		4096-QAM
MIMO	4×4 MIMO	4×4 MIMO, DL MU-MIMO	8×8 UL/DL MU-MIMO		16×16 UL/DL MU-MIMO


SU/MU-MIMO



UL MU-MIMO



DL MU-MIMO



MIMO in 802.11n

MCS index	Modulation	Coding rate	Antennas	20 MHz Mbps	40 MHz Mbps
0	BPSK	1/2	1	6.5	13.5
1	QPSK	1/2	1	13	27
2	QPSK	3/4	1	19.5	40.5
3	16-QAM	1/2	1	26	54
4	16-QAM	3/4	1	39	81
5	64-QAM	2/3	1	52	108
6	64-QAM	3/4	1	58.5	121.5
7	64-QAM	5/6	1	65	135


MCS index	Modulation	Coding rate	Antennas	20 MHz Mbps	40 MHz Mbps
8	BPSK	1/2	2	13	27
9	QPSK	1/2	2	26	54
10	QPSK	3/4	2	39	81
11	16-QAM	1/2	2	52	108
12	16-QAM	3/4	2	78	162
13	64-QAM	2/3	2	104	216
14	64-QAM	3/4	2	117	243
15	64-QAM	5/6	2	130	270

MIMO in 802.11ac

MCS index	Modulation	Coding rate	160 MHz Data rate (Mbps)			
			1x1	2x2	4x4	8x8
0	BPSK	1/2	65	130	260	520
1	QPSK	1/2	130	260	520	1040
2	QPSK	3/4	195	390	780	1560
3	16-QAM	1/2	260	520	1040	2080
4	16-QAM	3/4	390	780	1560	3120
5	64-QAM	2/3	520	1040	2080	4160
6	64-QAM	3/4	585	1170	2340	4680
7	64-QAM	5/6	650	1300	2600	5200
8	256-QAM	3/4	780	1566	3120	6240
9	256-QAM	5/6	866.7	1733.3	3466.7	6933.3

Omni-directional antenna


- Omni directional antenna
 - Commonly used in 802.11 WiFi networks
- Advantages
 - Coverage in all directions
 - Simpler hardware design
- Disadvantages
 - A large amount of radiated power is wasted



- Can we concentrate the radiated transmission energy towards the intended receivers?
 - Can increase SNR for intended receivers
 - Reduce interference to other devices


Omni-directional antenna

- Directional antenna
 - Widely used in special purpose applications
- Advantages
 - Higher signal strength in desired direction
 - Reduced interference to other devices
- Disadvantages
 - Coverage restricted to some direction
 - Costly - multiple antennas needed for omni coverage, capacity (similar to sectors used in cellular network base stations)
- **Solution – electronic beamforming**




Beamforming

- Beamforming
 - Use omni-directional antennas to focus signal in specific direction
 - Exploit multiple antennas used for MIMO




Beamforming

- Beamforming using multiple antenna



Beamforming

- Beamforming
 - Constructive interference
 - When signals meet in phase, resultant signal strength increases




Beamforming

➤ Beamforming

- Destructive interference
- When signals meet out of phase, resultant signal strength weakens



Easier to achieve in higher frequencies, why?
In 5GHz 1 wavelength = 6mm



Beamforming


➤ Beamforming

- Use omni-directional antennas to focus signal in a specific direction
- Change the phase of signal emitting from different antenna
- Intelligent phase modification can result in beams in desired direction




Same frequency,
different phase

Beamforming




Beamforming



Beamforming

- Channel sounding procedure
 - Explicit feedback
 - Beamformer asks the beamformee to provide a feedback of channel measurement



Channel matrix

Feedback matrix



- Channel State Information (CSI)
 - Also used as feedback for MIMO spatial multiplexing
 - Challenge – the CSI matrix can be very large in size, especially for wider channel widths (e.g. 160 MHz)
 - Frequent feedback necessary for accurate beamforming – high overhead

The quest for high speed wireless

➤ Applications driving the growth




High definition (4K and beyond)
video streaming

Tether less interfaces

Wireless USB, PCI buses, HDMI



Sync and go



Wireless docking,
screen mirroring


The quest for high speed wireless

➤ Virtual reality



<https://www.youtube.com/watch?v=Oxfj-qoV5KE>

Search for more bandwidth



60 GHz
ISM band

Search for more bandwidth

- How can we create wireless networks that can provide multi-gigabit per second data rate?
 - Per link speed should be > 3 Gbps

Millimeter wave wireless networks

Major millimeter wave
spectrum bands


Current WiFi operates
in 2.4 and 5 GHz

Spectrum bands	Bandwidth
28 GHz	1.3 GHz
39 GHz	1.4 GHz
60 GHz	14 GHz
74 GHz	5 GHz
84 GHz	5 GHz


ISM

60 GHz path loss

- How to deal with such high path loss?
 - Directionality – concentrate the radiated energy in one direction




Omni-directional
transmission



Directional
transmission

60 GHz Network



802.11ad frequency bands

57.05 GHz

64 GHz

60 GHz ISM band in USA/Canada



The diagram illustrates the frequency bands for 802.11ad. It features a large blue bar representing the 60 GHz ISM band in the USA/Canada, spanning from 57.05 GHz to 64 GHz. Below this, three smaller blue bars represent individual channels: Channel 1 (57.24 GHz to 59.40 GHz), Channel 2 (59.40 GHz to 61.56 GHz), and Channel 3 (61.56 GHz to 63.72 GHz). The channels are staggered horizontally to show their relative positions within the larger band.

Channel	Start Frequency (GHz)	End Frequency (GHz)
Channel 1	57.24	59.40
Channel 2	59.40	61.56
Channel 3	61.56	63.72

Channel 1

57.24 GHz

Channel 2

59.40 GHz



Channel 3

61.56 GHz

63.72 GHz

Human blockage



- 60 GHz networks
 - Human mobility – results in unpredictable blockage of links



Self blockage - human body blocks link to mobile device
- specifically a challenge for mobile devices

Blockage and mobility


- Two important open challenges
 - Blockage and mobility
- Blockage
 - Commonly caused by human mobility over Tx, Rx path
 - Human body blockage can result in complete link outage, especially when narrow beamwidth is in use
- Mobility
 - One or both endpoints of a 60 GHz link are mobile
 - Requires constant tracking of mobile endpoints
 - Beam steering – change beam direction based on observed direction




Two possible solutions

Beamwidth angle



Blockage



Beam steering




Mobility




Mobile and Wireless Networks

Cellular Structure

Cellular Network Organization




Frequency Reuse




Frequency Reuse

- Power of base transceiver controlled
 - Allow communications within cell on given frequency
 - Limit escaping power to adjacent cells
 - Allow re-use of frequencies in nearby cells
 - Use same frequency for multiple conversations
- *E.g.*
 - N cells all using same number of frequencies
 - K total number of frequencies used in systems
 - Each cell has K/N frequencies
 - $K=395$, $N=7$ giving 57 frequencies per cell on average


Frequency Reuse Patterns



(a) Frequency reuse pattern for $N = 4$




(b) Frequency reuse pattern for $N = 7$




(c) Black cells indicate a frequency reuse for $N = 19$


Frequency Reuse Distance



Cochannel Interference





Worst Case of Cochannel Interference





Increasing Capacity (1)

- Smaller clusters - here from 7 cells to 3 cells



Interfering cells are closer when cluster size is smaller.


Increasing Capacity (1)



Increasing Capacity (2)


➤ Cell Splitting

- Cells of high usage can be split into smaller cells
- Leads to increased capacity but more frequent handovers




Increasing Capacity (3)

➤ Smaller cells



(a) Cell radius = 1.6 km



(b) Cell radius = 0.8 km

Increasing Capacity (4)

- Cell Sectoring
 - Cell divided into wedge shaped sectors
 - 3 – 6 sectors per cell
 - Each with own channel set
 - Subsets of cell's channels
 - Directional antennas




Fig: omni-directional


60° sectoring

120° sectoring

Increasing Capacity (5)


➤ Microcells

- Move antennas from tops of hills and large buildings to tops of small buildings and sides of large buildings
 - Even lamp posts
- Form microcells with reduced power
- Good for city streets, along roads and inside large buildings



Multi-tier architectures

Base Station Types




Cell Type	Output Power (W)	Cell Radius (km)	Users	Locations
Femtocell	0.001 to 0.25	0.010 to 0.1	1 to 30	Indoor
Pico Cell	0.25 to 1	0.1 to 0.2	30 to 100	Indoor/Outdoor
Micro Cell	1 to 10	0.2 to 2.0	100 to 2000	Indoor/Outdoor
Macro Cell	10 to >50	8 to 30	>2000	Outdoor


Cellular Network Generations

- It is useful to think of cellular Network/telephony in terms of *generations*:
 - **0G**: Briefcase-size mobile radio telephones
 - **1G**: *Analog* cellular telephony (end '70s)
 - **2G**: *Digital* cellular telephony (beg '90's)
 - **3G**: *High-speed* digital cellular telephony (including *video telephony*) (beg '00)
 - **4G**: IP-based “anytime, anywhere” voice, data, and multimedia telephony at *faster* data rates than 3G (beg '10)
 - **5G**: 10-times faster data rates, much more flexible in mobility, Internet of Things (IoT) support (cheap, low energy, massive number of devices) (beg '20)


Evolution of Radio Access Technologies



Evolution of Cellular Standards




Evolution of Cellular Standards



Evolution of Cellular Standards


TechTrained.com



The Evolution of
Cellular Standards




Evolution of Cellular Standards




Global Convergence

- LTE is the major technology for mobile broadband communications
 - Convergence of 3GPP and 3GPP2 technology tracks
 - Convergence of FDD and TDD into a single technology track



Evolution of terminals and services



Business model evolution




2G




3G



4G



Business model evolution



Business model evolution




4G networks do not enable the range of services that the future requires. 5G will be faster and more flexible.


4G
network

5G network slicing


5G network slicing enables service providers to build virtual end-to-end networks tailored to application requirements.



A cellular network



LOCATION UPDATE



GSM


- Abbreviation for **Global System for Mobile Communications**
- In the mid 1980's, most of Europe didn't have a cellular network
 - They weren't committed to analog
- After many years of research, GSM was proposed around 1990
 - Covered Germany, France, England, and Scandinavia
 - In Greece GSM started in 1993
- Goals:
 - Roaming throughout all of Europe
 - Low power and inexpensive devices
 - All digital to offer 64kbps throughput
 - Never achieved

GSM Services


- Voice, 3.1 kHz
- Some data transmission is possible with **very low speeds** (originally 9.6kbps) – e.g. fax.
- Short Message Service (SMS)
 - 1985 GSM standard that allows messages of at **most 160 chars** (incl. spaces) to be sent between handsets and other stations
 - SMS was for years the most widely used data application in the world, with **3.6 billion active users**, or 78% of all mobile phone subscribers (2011).

GSM Frequencies

- Originally designed on 900MHz range, later available on 800MHz, 1800MHz and 1900 MHz ranges.
- Separate Uplink and Downlink frequencies
 - One example channel on the 1800 MHz frequency band, where RF carriers are spaced every 200 kHz




Uplink/Downlink frequency channels



GSM resource allocation


Copyright 2001 blueadmiral.co.uk




GSM System – Multiple Access

Time Division Multiple Access (TDMA)

992 voice channels/cell



GSM architecture



GSM main components

Base Transceiver Station (BTS): Encodes, encrypts, multiplexes, modulates and feeds the **RF signals to the antenna.**

Base Station Controller (BSC): **Manages Radio resources for BTSs,** assigns frequency and time slots for all mobile terminals in its area.

Mobile Switching Center (MSC): **Heart of the network,** call setup function and basic switching, call routing, billing information and collection, mobility management.

Home/Visiting Location Registers (HLR/VLR): permanent/temporary **database about mobile subscribers** in a large service area.


Authentication Center (AUC): Protects against intruders in air interface, maintains **authentication keys and algorithms.**

Equipment Identity Register (EIR): Database that is used to **track handsets** using the IMEI (International Mobile Equipment Identity).

GPRS (General Packet Radio Service)

- GSM upgrade that provides IP-based packet data transmission up to 171 kbps (never allowed)
- Users can “simultaneously” make calls and send data
- GPRS provides “always on” Internet access and the Multimedia Messaging Service (MMS)
- Performance degrades as number of users increase
- GPRS is an example of 2.5G telephony

GPRS Architecture




Main difference with GSM


SGSN (Serving GPRS Support Node): Packet switching with mobility management capabilities. Responsible for the delivery of data packets from and to the mobile stations within its geographical service area.

GGSN (Gateway GPRS Support Node): Packet switch interworking with other data networks (Internet). Converts the GPRS packets coming from the SGSN into the appropriate packet data protocol format (e.g., IP)

Routing in GPRS




GPRS System – Multiple Access



3G

- 3G refers to a **set of standards** that comply to IMT-2000 specifications by ITU
- The following standards are typically branded 3G:
 - the **UMTS system**, first offered in 2001, standardized by **3GPP**, used primarily in Europe
 - the **CDMA2000** system, first offered in 2002, standardized by **3GPP2**, used especially in North America

IMT-2000 Vision Includes LAN, WAN and Satellite Services




UMTS (Universal Mobile Telecommunications System)

- Voice quality comparable to the public switched telephone network
- 144 Kbps/user in high-speed motor vehicles
- 384 Kbps/pedestrian standing or moving slowly over small areas
- Up to 2 Mbps for fixed applications like office use
- Symmetrical/asymmetrical data transmission rates
- Support for both packet switched and circuit switched data services like Internet Protocol (IP) traffic and real time video


UMTS Frequency Spectrum

➤ UMTS Band

- 1900-2025 MHz and 2110-2200 MHz for 3G transmission
- In the US, 1710–1755 MHz and 2110–2155 Mhz is used instead, as the 1900 MHz band was already used.



UMTS Architecture



- UE (User Equipment) that interfaces with the user
- UTRAN (UMTS Terrestrial Radio Access Network) handles all radio related functionality – WCDMA is radio interface standard here.
- CN (Core Network) is responsible for transport functions such as switching and routing calls and data, tracking users

UMTS Network Architecture

- UMTS network architecture consists of three domains
 - **Core Network (CN):** Provide switching, routing and transit for user traffic
 - **UMTS Terrestrial Radio Access Network (UTRAN):** Provides the air interface access method for user equipment.
 - **User Equipment (UE):** Terminals work as air interface counterpart for base stations.

UMTS QoS Classes

Traffic class	Conversational class	Streaming class	Interactive class	Background
Fundamental characteristics	Preserve time relation between information entities of the stream Conversational pattern (stringent and low delay)	Preserve time relation between information entities of the stream	Request response pattern Preserve data integrity	Destination is not expecting the data within a certain time Preserve data integrity
Example of the application	Voice, videotelephony, video games	Streaming multimedia	Web browsing, network games	Background download of emails

UMTS QoS Classes

Conversational	Streaming	Interactive	Background
----------------	-----------	-------------	------------

low delay	reasonably low delay	low round-trip delay	delay is not critical
low delay variation			
basic QoS requirements			


speech	video streaming	www applications	store-and-forward applications (e-mail, SMS) file transfer
video telephony/conferencing	audio streaming	<i>basic applications</i>	

UMTS QoS Classes


Conversational	Streaming	Interactive	Background
----------------	-----------	-------------	------------

- low delay (< 400 ms) and low delay variation
- BER requirements not so stringent
- in the radio network => real-time (RT) connections
- speech (using **AMR = Adaptive Multi-Rate** speech coding)
- video telephony / conferencing:
 - ITU-T Rec. H.324 (over circuit switched connections)
 - ITU-T Rec. **H.323** or IETF **SIP** (over packet switched connections)

UMTS QoS Classes



- reasonably low delay and delay variation
- BER requirements quite stringent
- traffic management important (variable bit rate)
- in the radio network => real-time (RT) connections
- video streaming
- audio streaming



video or audio information is buffered in the UE,
large delay => buffer is running out of content!

UMTS QoS Classes


Conversational	Streaming	Interactive	Background
----------------	-----------	-------------	------------

- low round-trip delay ($< \text{seconds}$)
- delay variation is not important
- BER requirements stringent
- in the radio network \Rightarrow non-real-time (NRT) connections
- web browsing
- interactive games
- **location-based services** (LCS)

UMTS QoS Classes


Conversational	Streaming	Interactive	Background
----------------	-----------	-------------	------------

- delay / delay variation is not an important issue
- BER requirements stringent
- in the radio network => non-real-time (NRT) connections
- SMS (Short Message Service) and other more advanced messaging services (EMS, MMS)
- e-mail notification, e-mail download
- file transfer



Code Division Multiple Access (CDMA)




senders



Power control in WCDMA

❖ The purpose of power control (PC) is to ensure that each user receives and transmits just enough energy to prevent:

- ❖ Blocking of distant users (near-far-effect)
- ❖ Exceeding reasonable interference levels



3.5G (HSPA)

High Speed Packet Access (HSPA) is an amalgamation of two mobile telephony protocols, High Speed Downlink Packet Access (HSDPA) and High Speed Uplink Packet Access (HSUPA), that extends and improves the performance of existing WCDMA protocols

3.5G introduces many new features that enhance the UMTS technology. These include:

- Adaptive Modulation and Coding
- Fast Scheduling
- Backward compatibility with 3G
- Enhanced Air Interface

Service Roadmap

Improved performance, decreasing cost of delivery



A number of mobile services are bearer independent in nature

3G-specific services take advantage of higher bandwidth and/or real-time QoS

Multitasking
WEB browsing
Corporate data access
Streaming audio/video

Video sharing
Video telephony
Real-time IP multimedia and games
Multicasting

Broadband in wide area

Voice & SMS

MMS picture / video
xHTML browsing
Application downloading
E-mail
Presence/location
Push-to-talk

GSM
9.6
kbps


GPRS
171
kbps

EGPRS
473
kbps

WCDMA
2
Mbps

HSPA
1-10
Mbps

Typical average bit rates
(peak rates higher)



Long Term Evolution (LTE)
Long Term Evolution – Advanced (LTE-A)

IMT-Advanced

Item	IMT-Advanced
Peak Data Rate (DL)	1 Gbps
Peak Data Rate (UL)	500 Mbps
Spectrum Allocation	>40 MHz
Latency (User Plane)	10 ms
Latency (Control Plane)	100 ms
Peak Spectral Efficiency (DL)	15 bps/Hz (4 X 4)
Peak Spectral Efficiency (UL)	6.75 bps/Hz (2 X 4)
Average Spectral Efficiency (DL)	2.2 bps/Hz (4 X 2)
Average Spectral Efficiency (UL)	1.4 bps/Hz (2 X 4)
Cell-Edge Spectral Efficiency (DL)	0.06 bps/Hz (4 X 2)
Cell-Edge Spectral Efficiency (UL)	0.03 bps/Hz (2 X 4)
Mobility	Up to 350 km/h

Motivation for LTE

- Need for higher data rates and greater spectral efficiency
 - Can be achieved with HSDPA/HSUPA
 - and/or new air interface defined by 3GPP LTE
- Need for Packet Switched optimized system
 - Evolve UMTS towards packet only system
- Need for high quality of services
 - Use of licensed frequencies to guarantee quality of services
 - Always-on experience (reduce control plane latency significantly)
 - Reduce round trip delay
- Need for cheaper infrastructure
 - Simplify architecture, reduce number of network elements

Advantages of LTE

- ▶ High network throughput
- ▶ Low latency
- ▶ Plug & Play architecture
- ▶ Low Operating Costs
- ▶ All-IP network
- ▶ Simplified upgrade path from 3G networks

for Network Operators

- ▶ Faster data downloads/uploads
- ▶ Improved response for applications
- ▶ Improved end-user experience

for End Users

Mobile Network Evolution

1G

AMPS, NMT
TACS

2G

GSM/GPRS/
EDGE
cdmaOne

3G

WCDMA/HSPA+
CDMA2000/EVDO
TD-SCDMA

4G

LTE
LTE-A

1G

Mid 1980s

2G

1990s

3G

2000s

4G

2010s

5G

2020s

analog
voice



Digital voice
+ Simple data




Mobile
broadband



Mobile Internet
More & faster




Network Architecture Evolution




CS Signaling

- used to setup, maintain teardown VC
- used in 2G, as well as in 3G
- not used in today's Internet




Packet Switching (PS)



- Sequence of A & B packets does not have fixed pattern, bandwidth shared on demand → statistical multiplexing
- Store-and-forward at intermediate routers
- Used by the Internet

Comparison of LTE Speed

2G – 4G Data download rates




- 2.5G speed is based on the maximum offered by EDGE
- 3G speed is based on the maximum offered by HSDPA

LTE Evolution

- Specification managed by 3GPP organization
 - 3rd Generation Partnership Project
 - UMTS (Universal Mobile Telephone System) Rel 99
 - HSDPA (High Speed Downlink Packet Access) Rel 5
 - HSUPA (High Speed Uplink Packet Access) Rel 6
 - HSPA+ Rel 7, enhancements in Rel 8-10
- New LTE specification in Release 8-9
- LTE-A in Release 10

Release of 3GPP specifications



	WCDMA (UMTS)	HSPA HSDPA / HSUPA	HSPA+	LTE	LTE ADVANCED (IMT ADVANCED)
Max downlink speed (bps)	384k	14 M	28 M	100 M	1 G
Max uplink speed (bps)	128 k	5.7 M	11 M	50 M	500 M
Latency round trip time (approx.)	150 ms	100 ms	50 ms (max)	~10 ms	Less than 5 ms
3GPP releases	Rel 99/4	Rel 5/6	Rel 7	Rel 8/9	Rel 10
Approx years of initial roll out	2003/4	2005/6 HSDPA 2007/8 HSUPA	2008/9	2009/10	
Access methodology	CDMA	CDMA	CDMA	OFDMA/SC- FDMA	OFDMA/SC- FDMA

LTE performance requirements


- Data Rate:
 - Instantaneous downlink peak data rate of 100Mbit/s in a 20MHz downlink spectrum (i.e. 5 bit/s/Hz)
 - Instantaneous uplink peak data rate of 50Mbit/s in a 20MHz uplink spectrum (i.e. 2.5 bit/s/Hz)
- Cell range
 - 5 km - optimal size
 - 30km sizes with reasonable performance
 - up to 100 km cell sizes supported with acceptable performance
- Cell capacity
 - up to 200 active users per cell(5 MHz) (i.e., 200 active data clients)

Key parameters of LTE

Frequency Range	UMTS FDD bands and UMTS TDD bands					
Channel bandwidth 1 Resource Block (RB) =180 kHz	1.4 MHz	3 MHz	5 MHz	10 MHz	15 MHz	20 MHz
	6 RB	15 RB	25 RB	50 RB	75 RB	100 RB
Modulation Schemes	Downlink	QPSK, 16QAM, 64QAM				
	Uplink	QPSK, 16QAM, 64QAM (⇒ optional for handset)				
Multiple Access	Downlink	OFDMA (Orthogonal Frequency Division Multiple Access)				
	Uplink	SC-FDMA (Single Carrier Frequency Division Multiple Access)				
MIMO technology	Downlink	Wide choice of MIMO configuration options for transmit diversity, spatial multiplexing, and cyclic delay diversity (max. 4 antennas at base station and handset)				
	Uplink	Multi-user collaborative MIMO				
Peak Data Rate	Downlink	150 Mbps (UE category 4, 2x2 MIMO, 20 MHz) 300 Mbps (UE category 5, 4x4 MIMO, 20 MHz)				
	Uplink	75 Mbps (20 MHz)				

Multi-tier Architecture


One technology



LTE frequency bands



UMTS Architecture



- UE (User Equipment) that interfaces with the user
- UTRAN (UMTS Terrestrial Radio Access Network) handles all radio related functionality – WCDMA is radio interface standard here.
- CN (Core Network) is responsible for transport functions such as switching and routing calls and data, tracking users

LTE Architecture

